


## FITTINGS CROSSES - HOSE CAPS - DISTRIBUTION BLOCKS

### Female distribution block - A16



#### Min / Max operating pressure

0 / 15 bar

Part number	Female thread	Dim. A (mm)	Dim. B (mm)
A16 3814S2	G3/8; G1/4	72	30
A16 3814S3	G3/8; G1/4	108	30
A16 3814S4	G3/8; G1/4	144	30
A16 3814S5	G3/8; G1/4	180	30
A16 3814S6	G3/8; G1/4	216	30